

WHITE KNUCKLE



OFF ROAD PRODUCTS®

OFF ROAD VEHICLE BODY PROTECTION

INEOS GRENADIER

Thank you for choosing White Knuckle Rock Sliders

Please read instructions before beginning installation. Check hardware kit contents against content list below.
Also, check the tools needed against the list below.

Hardware Kit

- 1-Drivers Side Rock Slider
- 1-Passenger Side Rock Slider
- 16 – M10 x 30mm Hex Head Screws and Flat Washers
- 8 – M10 x 30mm Hex Nuts
- 6 – M12 x 30mm Hex Head Screws and Flat Washers

Tools Needed

- 19mm & 17mm Sockets
and Ratchet
- 17mm Wrench
- 2 Axle Stands
- Floor Jack (Optional)

INSTALLATION INSTRUCTIONS

1. We recommend cleaning the threaded holes to be used in the frame with spray lubricant and/or wire brush.
2. Place the axle stands directly under the rocker panel. Place the rock slider on the axle stands. Place another axle stand or floor jack under the center mounting leg to keep the slider from swinging out and to provide more stability. **Optional:** Place a floor jack under the center of the rock slider and lift until the bolt holes line up between the vehicle frame and the rock slider mounting plates.
3. Lift the slider until the mounting plates holes line up with the corresponding frame holes.
4. Begin threading the **three** 12mm screws with flat washers in the center mounting plate.
5. Next, begin threading the **four** 10mm screws with flat washers through the front mounting plate.
6. Finish at the rear mounting plate with the **four** 10mm screws, flat washers and nuts.
7. Once all the screws have been started, tighten all the screws and then recheck each bolt for tightness.



SAFETY FIRST

Observe proper safety procedures during installation. Improperly used tools and unsafe procedures can cause injury or death. Refer to manufacturers manuals for use and warnings of tools to be used. Modifications to your vehicle can cause dangerous conditions. The buyers and users of this product assume all risks associated with the installation and use of this product. All installations should be made by a qualified mechanic.

DISCLAIMER

White Knuckle Off Road Products, LLC stands behind all of our quality off-road fabricated products. White Knuckle Off Road Products, LLC will not be held responsible nor will we accept liability for failure of parts as a result of extreme off-road use. Minor modifications may be required to allow the installation of our products. Modifications to your vehicle using products manufactured by White Knuckle Off Road Products, LLC may create dangerous conditions. Modifications to your vehicle are done at your own risk. White Knuckle Off Road Products, LLC will not accept responsibility or liability from damage or personal injury caused by installing or using installed products manufactured by White Knuckle Off Road Products, LLC whether intended or unintended. The buyer/user accepts all responsibility and risks associated with any modifications and use of White Knuckle Off Road Products, LLC manufactured products. All products manufactured by White Knuckle Off Road Products, LLC are for off-road use only.

POWDER COAT FINISH

The powder coat finish provided by White Knuckle Off Road Products, LLC will carry NO warranty or guarantee of any kind. The powder coat finish is provided as a service only. Any damage to the finish during shipping is the responsibility of the delivery company and NOT the responsibility of White Knuckle Off Road Products, LLC. Any damage incurred during shipping MUST be noted on the Bill Of Lading or to UPS at the time of delivery. The delivery companies will not honor any claims made after the product has been delivered and damage had not been noted at the time of delivery as mentioned above. Customer provided shipping is also an option. Any damage, wear, or anomalies incurred to the finish after receiving parts from White Knuckle Off Road Products, LLC are the responsibility of the buyer or user.